

## Installation guide S10 Blast Front Upper Carbon Chassis Brace #124611 taking the example of a S10 Blast TX 2



### Tools required

- LRP WorksTeam Tools Philipps, small #65771
- LRP WorksTeam Tools 2.0mm Hex # 65651

**Please note:** Seal the carbon part as explained in the sheet enclosed into the package.

- 1) Loosen the tagged screws and remove the top deck.





2) Insert the carbon top deck and screw it down.

